

Installing your ShowerTwin shower head



EASY DO-IT YOURSELF INSTALLATION INSTRUCTION'S

1. Remove old shower head (REMOVE ALL TEFLON TAPE) and clean pipe thread thoroughly.
2. NO TEFLON TAPE IS USED DURING THE INSTALLATION OF THIS PRODUCT.
3. Hold the Shower Twin Plus manifold to the shower pipe and finger tighten the swivel nut (with clear washer) to the pipe until firmly seated. Now tighten the swivel nut a 1/4 to 1/2 turn with pliers to secure it.
4. Thoroughly clean and dry the tile location where the sliderbar will be mounted.
5. We recommend nail polish remover to prep the tile surface (wait until dry) before continuing.
6. Peel off the back of the adhesive pads on the sliderbar.
7. Press and hold for (30 seconds) onto the desired location.
8. Please allow 24 hours for a full bound to take place.
9. Insert one black washer to the stainless hose and thread hose to the center bottom of the Shower Twin Plus manifold. Next insert the second black washer into the bottom of the stainless hose and connect it to the handheld showerhead. Next place handheld in the slider bar holder.
10. For installation of the wall mount use same technique as the sliderbar.

CONGRATULATIONS!

YOU ARE NOW READY TO ENJOY YOUR SHOWERTWIN LUXURY BATH SYSTEM



EASY DO-IT-YOURSELF INSTALLATION

1. Remove old shower head (REMOVE ALL TEFLON TAPE) and clean pipe thread thoroughly.
2. NO TEFLON TAPE IS USED DURING THE INSTALLATION OF THIS PRODUCT.
3. Hold the Shower Twin manifold to the shower pipe and finger tighten the swivel nut (with clear washer) to the pipe until firmly seated, now tighten the swivel nut a 1/4 to 1/2 turn with pliers to secure it.

CONGRATULATIONS!

YOUR ARE NOW READY TO ENJOY YOUR SHOWERTWIN

Office : (941)752-0913 | Fax: (941)752-0813 | Email: showertwin@att.net